

verselo® classic



Fitting Instructions

1 - Before you order

Check if your window is suitable

The **Verselo Classic** window handle is for standard espagnolette windows, which are the standard for modern double-glazed windows, often with handles that feature locking mechanisms for added safety. For our **Verselo** handle to fit, the distance between the centre of each screw hole on your existing handle should be 43mm. You can check this with a tape measure/ ruler.

The **Verselo Classic** handle is slightly longer than traditional window handles, so it is unsuitable for very small windows, such as you may find in a small bathroom. As shown in the images on the right, the internal opening size must be greater than 300mm.



2 - Before you order

Find out what spindle length you need.

You will need to remove your existing window handle to find out what spindle length you need. Use a screw driver to remove the existing screws. You may need to remove a small screw cap. The other screw is often found underneath the handle.

After the handle is removed, rest a tape measure against the spindle (the metal sticking out the back of the handle) so it touches the side of the handle, like in the image to the right. Make a note of this length. We offer standard spindle lengths, as well as custom spindle lengths in multiples of 5mm (you may need to size up).

This is a great opportunity to also check that the width of the spindle is 7mm.



verselo® classic

Fitting Instructions

3 - Once your order arrives

Fit your new Verselo Classic handle

The **Verselo Classic** handle arrives already locked, so you will need to use the key to unlock it. Then remove the screw cap cover at the top of the **Verselo handle**, and remove your existing handle from your window, as explained on page 1. When you fit the **Verselo** handle, make sure it is in the same alignment as your existing handle was when you removed it, or the locking mechanism will not match up.

Push the handle gently against the frame and, with the supplied screws, secure the handle in place using a screwdriver. Please note: there are three screw holes on the **Verselo Classic** handle, but the third screw hole at the bottom of the handle is not needed. If you think it is, there may be a compatibility issue and you should get in touch with us.

Check the handle opens and closes as expected, then push the screw cover in.

3 - Once your order arrives

How to use your Verselo Classic handle

It is important to remember that the key must be removed from the handle before you operate it.

Simply slide the lock down with a gentle touch and the handle will 'pop' open. Operate the handle as normal. When you want to lock the handle, make sure the window is closed, and move the handle slightly past its central position, then move it back to its central position. Click the handle back into place and lock it using the key.

